


VITA - VACUMAT 100

Operating Manual



Contents

1. Technical Specifications	2
2. Setting the Furnace Up for Use	2
3. Operating the Furnace	3
4. The Display Indicator Panels	4
5. Error messages	5
6. The Programs	6
7. Changing the Information Stored in a Program	7
8. Example for Program 4.	8
9. Firing Chart	9
10. Eliminating Program Faults	10
11. Changing the Muffle	11
12. Altering the Starting Temperature	11
12.1. Altering the Starting Temperature – Version lower than 8.0:	11
12.2. Altering the Starting Temperature – Version 8.0 onwards:	12

1. Technical Specifications

Dimensions:	height	50,0 cm
	width	35,0 cm
	depth	36.5 cm
Weight (excluding pump):	22 Kg	
Firing chamber (utilizable space):	diameter	9.6 cm
	height	7.0 cm
Power Supply:	240 Volts A.C., 50 / 60 Hz	
	220 Volts A.C., 50 / 60 Hz	
	110 Volts A.C., 50 / 60 Hz	
Maximum power consumption:	1600 Watts / 8 Amps	
Maximum temperature:	1200°C	
Vacuum Pump:	Typ: PM 29, 220 Volts A.C., 50 / 60 Hz	
	Typ: PM 29, 240 Volts A.C., 50 / 60 Hz	
	Typ: PM 29, 110 Volts A.C., 50 / 60 Hz	
	Weight: 6.4 Kg	

Supply Schedule:

1 special packing case containing:

1 VITA Vacumat 100 furnace	plus as an optional extra 1 vacuum pump type PM 29 complete with 1 vacuum hose
1 firing tray	
1 pair of 25cm furnace tweezers	
1 main power lead complete with plugs	
1 set of firing trays A and B, grey	
1 set of porcelain trays G, grey	
1 operating instruction manual	
1 firing charts	

All specifications subjects to change without notice.

2. Setting the Furnace Up for Use

Note: When positioning the furnace, a minimum of 25cm space should be allowed for between it and any wall, either to the rear or sides.

- Using the supplied main power lead, connect the furnace up to an electrical power supply that is appropriate for the model, i. e. either 240 Volts A.C., 50 / 60 Hz; 220 Volts A.C., 50 / 60 Hz; 110 Volts A.C., 50 / 60 Hz.
- Connect the plug of the vacuum pump up to the round socket(13) at the rear of the furnace, and then press the vacuum hose onto the nozzle (14) also at the rear of the furnace.
- Press the power on/off switch (9) in. The green indicator light inside the switch will then come on, and the firing tray lift (3) will descend to its lower position.
- Place the supplied firing tray (2) onto the lift support plate.
- Press key „A“ of the programming input keys (4), which will send the firing tray lift up into the firing chamber. The temperature inside will then rise until it reaches the starting temperature and then remain steady.

Once the starting temperature has been reached, the furnace is ready for firing using any program.

3. Operating the Furnace

The Power On/Off Switch:

By pressing in the power on/off switch (9), the furnace is turned on, which is indicated at all times by the green light inside the switch. In addition to this green indicator light, the current temperature display indicator will also light up the showing the temperature inside the firing chamber. The furnace is turned off by re-pressing the power on/off switch (9).

The Manual Control Keys for the Firing Tray Lift:

By pressing the upper lift key (8), the firing tray can be raised up into the firing chamber, and by pressing the lower lift key (8) the firing tray can be brought down out of the firing chamber. To operate either of these lift keys (8), the appropriate one should be pressed continuously until the lift has reached the desired position.

The Program Activate Key „START“:

All programs are started by pressing the program activate key „START“ (5).

The Program Interrupt Key „STOP“:

Pressing the program interrupt key „STOP“ (6) will result in the following sequence:

1. The firing tray lift will descend out of the firing chamber to its lower position. This applies even if the program is interrupted during a firing sequence, although if vacuum is existing, the firing chamber will first be fully flooded with air to equalize the atmospheres;
2. The acoustic signal will then sound to indicate the end of the program, and should be cancelled by pressing key D.

The Programing Input Keys:

Figures 0 to 9 on the programing input keys are used to select a program, as well as to set or alter the end temperature setting and all the time settings in a program.

For programing, the following values can be set:

Pre-drying time:	0 to 99 min. (in full minutes only)
Heating-up time:	3.0 – 20.0 min. (in full minutes and tenths of a minute)
End temperature firing time:	0 to 40.0 min. (in full minutes and tenths of a minute)
Vacuum firing time:	0 to 60 min. (in full minutes only)
Endtemperature:	maximum 1200°C



Key A – The Starting Temperature Key is used first of all, before any other program, to prepare the furnace for firing by raising the firing tray lift, heating the firing chamber up to the starting temperature, and then continue to hold it steady.

Key B – is non functional

Key C – The Corrector Key can be used to correct the end temperature setting or any the time setting if they have been wrongly programmed. Immediately after an incorrect number or numbers have been pressed, key C should be pushed, which will cancel that particular setting so that the correct one can then be newly programmed.

Key D – The Acoustic Signal Cancel Key is used to cancel the acoustic signal at the end of a program.

Key E – The Zone Access Symbol ▲ Immediate Cancel Key


After having pressed the key F to store a setting, key E can then be pressed to immediately cancel the zone access symbol ▲. This therefore avoids having to press key F until the zone access symbol ▲ no longer appears on the display indicator panels.

Key F – The Zone Access Symbol Key

is used to call up, to move, and to cancel the zone access symbol ▲ on the display indicator panels. Moving the zone access symbol ▲ on to the next program sequence zone also stores a setting that has just been altered.

4. The Display Indicator Panels

- a (Progr.) = the program indicator
- b = the end temperature indicator
- c = the current temperatur indicator
- d  = the pre-drying time indicator
- e  = the heating-up time indicator
- f  = the end temperature firing time indicator
- g „VAC.“ = the vacuum firing time indicator
- h „bar“ = the vacuum indicator
- i = the time elapsed indicator
- k „F“ = the fault localization indicator



The program Indicator a (PROGR.) shows:

1. The number of the program that is currently in operation (i.e. numbers 1 to 9);
2. The termination or end of a program (i.e. E for End)
3. That the furnace is in a standby condition with the starting temperature being held steady (i.e. H for Hold).

The End Temperature Indicator b shows:

The end temperature that has been programed, between 20 and 1200°C.

The Current Temperature Indicator c (underlined in red) shows:

The current temperature inside the firing chamber, between 20 and 1200°C.

Indicator d  shows:

The pre-drying time that has been programed, in full minutes.

Indicator e  shows:

The heating-up time that has been programed, in full minutes and tenths of a minute (0.1 min. = 6 seconds).

Indicator f  shows:

The end temperature firing time that has been programed, in full minutes and tenths of a minute (0.1 min. = 6 seconds).

Indicator g „VAC“ shows:

The vacuum firing time that has been programed, in full minutes.

Indicator h „bar“ shows:

The degree of vacuum existing in the firing chamber, from 0 to minus 1 bar.

Indicator i shows:

The time that already elapsed within each sequence of a program, the sequence that is operating being indicated by the zone functioning symbol ▲

Indicator k shows:

„FEHLER“ gives notice of certain malfunctions an misprogramings, and at the same time also localizes them using the following code numbers:

5. Error messages

Error 0	pry-drying-temperature lower than 50°C (only in program no. 9)	
Error 01	over-temperature or break-down of thermocouple	
Error 02	break-down of thermocouple	
Error 03	no or lower vacuum after 20 sec.	
Error 04	actuell-temperature higher as calculated / adjusted rising temperature	
Error 05	rising time	> 20 minutes
Error 06	firing temperature	< pry-drying-temperature
Error 07	vacuum time	= („0000“)
Error 08	firing time within firing chamber	> 30 minutes
Error 09	firing temperature	> 1.200°C
Error 10	pry-drying-temperature	< 200°C or > 700°C
Error 20	temperature-off-set	> 20°C
Error 30	pry-drying-temperature	invalid sign
Error 31	firing temperature	invalid sign
Error 32	pry-drying-time	invalid sign
Error 33	rising-time	invalid sign
Error 34	firing-time	invalid sign
Error 35	vacuum-time	invalid sign
Error 36	cooling-temperature / program 7	invalid sign
Error 37	cooling-temperature / program 8	invalid sign
Error 40	pry-drying-temperature	value = „0000“
Error 41	firing temperature	value = „0000“
Error 42	pry-drying-time	value = „0000“
Error 43	rising-time	value = „0000“
Error 44	firing-time	value = „0000“
Error 45	vacuum-time	value = „0000“
Error 46	cooling-temperature / program 7	value = „0000“
Error 47	cooling-temperature / program 8	value = „0000“
Error 50	cooling-temperature / program 7	chosen value too high (> 1.200°C)
Error 51	cooling-temperature / program 8	chosen value too high (> 1.200°C)
Error 52	cooling-temperature / program 7	firing temperature is missing
Error 53	cooling-temperature / program 8	firing temperature is missing
Error 66	pry-drying-temperature	is about 100°C too high
Error 67	actuell IST-temperature	is about 30°C too high
Error 98	error within the furnace	faulty memory
Error 99	error within the furnace	faulty memory

The Zone Access / Zone Functioning Symbol ▲

appears under the end temperature, and the other time settings, when key F is pressed following one of the numbered program keys. The first time key F is pressed, it will appear under the end temperature indicator, and the second time it is pressed, it will appear under the time setting of the first sequence zone of the program that has been keyed. The setting under which the symbol appears can then be changed using the programming input keys. Once the required setting has been changed, either keys F should be pressed until the symbol ▲ no longer appears on either of the display indicator panels, or first key F to store the setting and the key E to immediately cancel the symbol.

When a program is in operation, the symbol ▲ will again appear, but as the zone functioning symbol. In this case it purely indicates which of the program sequence zones is currently in operation. It should not be confused with the zone access symbol.

6. The Programs

NOTE: The pre-drying temperature is always the same as the starting temperature. If the starting temperature has been changed from the original 600°C setting, the pre-drying temperature will have been changed, and will correspond to whatever the new starting temperature is.

Program	Program Cycle	Pre-Drying	Heating-Up	End tem. Firing	Slow Cooling
A	This is for use before any of the other programs and heats the firing chamber up to the starting temperature				
1	Heating-up to a given end temperature, in as short a time as possible (non-programable) followed by continued firing in the end temperature for a given time period.				
2	The same as program 1, but with a period of the firing cycle in vacuum				
3	Heating-up to a given end temperature, in a given time period, followed by continued firing at the end temperature for a given time period				
4	The same as program 3, but with a given period of the firing cycle in vacuum.				
5	Pre-drying for a given period of time, then heating-up to a given end temperature in a given time period, all followed by continued firing at the end temperature for a given period of time.				
6	The same as program 5, but with a given period of the firing cycle in vacuum.				
7	The same as program 5, but with an additional controlled slow cooling sequence for lowering the temperature back to the starting temperature. i.e. After the firing cycle proper has finished, the firing tray will lower itself to the middle pre-drying level, and will only lower itself completely when the temperature inside the firing chamber has sunk back to the starting temperature.				
8	The same as program 6, but with the same additional controlled cooling sequence that is described in program 7				

9 This speeds up the cooling of the firing chamber back to the starting temperature. To begin with, the firing tray will remain in its lower position, whilst the vacuum pump switches itself on, and remains on until the temperature inside the firing chamber has been lowered to 50°C below the starting temperature. The vacuum pump will then turn itself off, and the firing tray will be raised up into the firing chamber, closing off the entrance and thereby ensuring that the starting temperature is held steady.

7. Changing the Information Stored in a Program

Once a program has been selected, all time setting, as well as the end temperature setting, that are stored in that particular program, will be shown on the display indicator panels. (When new, the VITA Vacumat 100 is factory pre-programmed with the temperature and time settings that are required for firing VITA VMK 68 procelain). Each of these settings can be changed individually using the following instructions:

By Pressing key F, the zone access symbol ▲ will first appear under the end temperature setting. This then allows a new end temperature setting to be made using the numbered programming input keys. By re-pressing key F, this new end temperature (or the old unchanged one) is stored into the program, and the zone access symbol ▲ automatically moves on, to position itself under the next time setting that is part of the program that has selected. This time setting can then also be altered (or not) in exactly the same way as the first one. If no other setting in the program is to be altered, providing key F has first been pressed to store a changed setting, key E can then be pressed to immediately cancel the zone access symbol ▲. The basic rule is that a setting can always be changed if the zone access symbol ▲ is lit up under it.

The heating-up and endtemperature firing times are programmed in full minutes, followed by tenths of a minute. Therefore, if 17 is programmed, it will result in the time setting of 1.7 min. (1minute and 42 second).

The pre-drying an vacuum firing times, however, are only programmed in full minutes. Therefore, if 17 is programmed, it will here result in the time setting of 17 minutes.

In order to then be able to start a program once it has been selected and altered, the zone access symbol ▲ should no longer be visible under any of the program setting. If necessary, therefore, key F should first be pressed to store any new setting, followed by key E to immediately cancel zone access symbol ▲. As an alternative, key F can simply be pressed until the symbol no longer appears on either of the display indicator panels.


Once a program has been started, the same symbol ▲ appears as the zone functioning symbol on the lower display indicator panel, under the setting in the sequence zone that is currently in operation. This should not be confused with the zone access symbol.

Note: The starting temperature has been factory pre-set at 600°C. If so desired, however, this temperature can be altered, for which the furnace casing has first to be opened up. For precise details on this (only be carried out by, or under the supervision of VITA authorized personnel).

8. Example for Pogram 4.

Program 4 includes: Heating-up to a given end temperature in a given time period; continued firing at the end temperature for a given time period; with a given period of the firing cycle in vacuum.

The furnace should first be switched on and them be heated up to the starting temperature. The firing tray lift should then be completely retracted to its lowest position.



The programme will now commence and run automatially trough to completion using all the instructions shown on the display indicator panels.

9. Firing Chart

Material	Firing	Progr.	°C	→	↗	→	VAC
VITA VMK 68 with precious metal alloys	Oxidation	1	960			5.0	
	Paint-On 88 opaque	4	930		3.0	1.0	3
	Main vacuum	6	930	6	6.0	1.0	6
	1st correction	6	920	6	6.0	1.0	6
	2nd correction	6	910	6	6.0	1.0	6
	Glaze	3	930		3.0	1.0	
	Glaze, using VITACHROM „L“ Stains and Fluid	5	930	6	3.0	1.0	
Glaze, using VITACHROM „L“ Glaze No. 725	5	900	6	3.0	1.0		
VITA VMK 68 with non precious metal alloys	Paint-On 88 opaque	4	930		3.0	1.0	3
	Main vacuum	8	930	6	6.0	1.0	6
	1st correction	8	920	6	6.0	1.0	6
	2nd correction	8	910	6	6.0	1.0	6
	Glaze	7	930	6	3.0	1.0	
	Glaze, using VITACHROM „L“ Stains and Fluid	7	930	6	3.0	1.0	
	Glaze, using VITACHROM „L“ Glaze No. 725	7	900	6	3.0	1.0	
VITADUR - N	Core and Vita Pt opaque	4	1120		6.0	2.0	6
	Core, using a Vitadur profile	6	1120	6	6.0	2.0	6
	Main vacuum	6	960	6	6.0	1.0	6
	1st correction	6	950	6	6.0	1.0	6
	2nd correction	6	950	6	6.0	1.0	6
	Glaze	3	940		3.0	1.0	
	Glaze, using VITACHROM „L“ Stains and Fluid	5	940	6	3.0	1.0	
	Glaze, using VITACHROM „L“ Glaze No. 725	5	920	4	3.0	1.0	

Note: Times are given in minutes or minutes and tenths of a minute (i.e.6:0). Where a full minute is followed by a decimal point and then a nought (i.e. 6:0), this nought **must** be included in the programing! Otherwise the result will be in tenths of a minute (i.e. 0:6 min.).

Programing examples: For pre-drying time and vacuum firing time 6 min., press key 6 only; for heating-up time and temperature firing time 6:0 min., press key 6 followed immediately by key 0.

VITA Spectra – Seal

Program settings: 5, end temperature 1040 °C, pre-drying time 2 Min., heating-up time 6,0 Min., endtemperatre firing time 0,0 Min.

VITA Metall - Corrector

Program settings: 5, end temperature 1040 °C, pre-drying time 2 Min., heating-up time 6,0 Min., endtemperatre firing time 1,0 Min.

Soldering in the VITA VACUMAT

Method 1 - In-Furnace Soldering

Preheat the restoration, complete with flux and beads solder, in a preheating furnace for 15 – 20 min. at 400°C.

Program no. 5

Set final temperature by adding 50 °C to melting point of solder.

Pre-drying time: 5.00 min
Heating-up time: 5.00 min
Hold time: 3.00 min

Method 2

Preheat the restoration, with flux but without solder, in a preheating furnace for 15 – 20 min. at 400°C.

Program no. 5

Set final temperature by adding 50 °C to melting point of solder.

Pre-drying time: 1.00 min
Heating-up time: 3.00 min
Hold time: 4.00 min

10. Eliminating Program Faults

(only be carried out by, or under the supervision of VITA authorized personnel)

a) The temperature does not rise:

1. The first possibility is that the fuses (11) at the rear of the furnace have blown, for which the remedy is simply to replace the fuses.
2. The second possibility cause is that the muffel is defective, for which the remedy is to replace the muffel.

b) No vacuum is produced:

Check and clean the ring seal around the edge of the firing tray lift, and then also check and clean the lower rim of the firing chamber where the lift seal meets it.

Note: This fault will be shown by code number 3 on the fault localization indicator (k).

c) Other problems with the programming

Most other problems that might occur with the Vita Vacumat 100 can be corrected simply by replacing one or more of side-in control modules. For advice and diagnosis of any problems, you should contact your Vita dealer, or in case of difficulty:

The Furnace Servicing Dept.
VITA Zahnfabrik
Postfach 13 38
D – 79713 Bad Säckingen
West Germany
Telephone 07761 – 562 222

Caution! Before opening the furnace for any reason, **always** isolate it from the electricity supply!

11. Changing the Muffle

(only be carried out by, or under the supervision of VITA authorized personnel)

1. The furnace should first of all be isolated from its electrical power supply by removing its plug from the socket.
2. The 4 screws on the sides of the anodized top cover of the furnace should next be unscrewed and then removed together with their screw cups, and then the cover itself be lifted off.
3. The 6 screws in the top cover of the firing chamber should next be unscrewed, and then this also be lifted out.
4. After removing the insulating disc and insulation slab, the wires from the thermocouple can then be disconnected and the insulation stone complete with thermocouple be lifted out.
5. The wires from the defective quartz glass spiral muffle should now be disconnected, and then this also be lifted out.
6. The new muffle can now be placed into position, and then the furnace be reassembled in reverse order to that given above.

CAUTION! Do not forget to reconnect the earthed conductor wire to the anodized furnace top cover!!

12. Altering the Starting Temperature

(only be carried out by, or under the supervision of VITA authorized personnel)

12.1. Altering the Starting Temperature – Version lower than 8.0:


The starting temperature of the Vita Vacumat 100 has been factory pre-set at 600°C. Using the instructions that follow, however, it is possible to alter this internally, in 50°C steps, to any temperature between 200 and 600°C.

NOTE: The pre-drying temperature is always the same as the starting temperature. Changing the starting temperature therefore also changes the pre-drying temperature.

The furnace should first of all be isolated from the power supply by removing its plug from the socket. The 6 screws securing the cover of the lower instrumentation section of the furnace should next be unscrewed and removed together with their screw cups, and then the cover itself be lifted off.

The plug of the slide-in module nearest to the front control panel on the left-hand side of the furnace, the CPU microprocessor module, should now be released by simultaneously pushing the upper lever on the plug upwards and the lower lever downwards. This operation also partly disengages the plug which should then be pulled off completely.

The module's red safety locking device can now be pushed downwards, and the module itself be pulled completely out. On the right-hand side of the front of the module there is a switching unit with 8 individual small slide switches. It is through the positions of these switches that the level of the starting temperature is determined. The various temperatures are written just below each switch. For 200°C, all switches should be in the upward setting.



To alter the starting temperature, the switch that is already down should first be pushed upwards, and then the switch for the required temperature be pushed downwards in the direction of the written temperature numbers. All other switches except this one should now be in the upper position away from the temperature numbers.

The furnace's starting temperature will now correspond to that temperature which is written below the switch that has been pushed downwards. If none of the switches are down, the starting temperature will automatically be 200°C.

CAUTION! There should only be **one** of the eight switches pushed downwards at any one time, as otherwise incorrect temperatures will result.


Having had the starting temperature satisfactorily altered, the CPU microprocessor module can now be slid back into position, its plug be fixed back into place, with the upper lever pushed downwards again and the lower level pushed upwards again, this securing the plug in position. The cover of the furnace's lower section should then be replaced and secured in position with its screws.

Note: The two longer screws belong in the two holes at the rear of the upwards facing flat surface.

CAUTION! Do not forget to reconnect the earthed conductor wire to the anodized lower section cover!!

12.2. Altering the Starting Temperature – Version 8.0 onwards:

1. Switch furnace on.
2. Press button „E“, Display will show last used temperature.
3. Insert new stand-by-temperature (max. 700°C).
4. Press button „F“, new value will be stored.



1. firing chamber
2. firing tray socket
3. firing tray lift
4. programming input keys
5. programming activate key „START“
6. programming activate key „STOP“
7. display indicator panels
8. manual control keys for firing tray lift
9. power on/off switch
10. heat resistant surface for placing object when removed from firing tray
11. furnace fuses
12. socket for main power lead
13. socket for vacuum pump
14. nozzle for vacuum pump hose